



PHANTOM 8000 THERMIC -

Using the integrated Thermic Power Switch in the Phantom 8000 Thermic HD gaiter:

Connect all cables per the instructions on the Thermic footbed box. Push and hold the Thermic power button on gaiter for 2-3 seconds to turn on system. (The red light flashes rapidly during this process.) Once you release the button the “T” will flash with a single pulse pattern. The footbed is now in the **Low heat mode** with approximately 16 hours of battery life.

1. Push the button again quickly (no not hold down) and it will now flash with a double pulse pattern. The boot is now in the **Medium heat mode** with approximately 8 hours of battery life.
2. Push the button again quickly (do not hold down) and the “T” will glow solid red, no flashing. This is the **High heat mode** with approximately 4 hours of battery life.
3. Pushing the button again quickly (do not hold down) at this point will return the boot to the Low heat mode, and you can cycle through the modes again as described above.
4. Push and hold the button for 2-3 seconds to turn off system. (The red light flashes rapidly during this process.)

From Switch (Red end) to Battery (USB-A)



From footbed to switch (blue end)

